

# How to Order

An HES electric strike is really an “electric strike system” composed of a strike body, faceplate and accessories. Most faceplates and accessories are interchangeable within a series and must be ordered separately. Please enter each component on a separate line (see example below).

## Electric Strike Body Ordering

strike series	fail safe or fail secure	voltage	finishes	optional features
Choose electric strike series number	Specify an “F” for Fail Safe (Fail Secure is standard)	Specify voltage when ordering a 7000, 7500 or 660	Choose finish number	This item refers to options such as latchbolt monitor, strike switches, etc.

## Example of Electric Strike Body Ordering

(a) To order a 1006 series that is fail safe in a 630 finish with a latchbolt strike monitoring option, write:

- 1006-F-12/24-630-LBSM

To order a second 1006 series that is fail secure in a 630 finish, write:

- 1006-12/24-630

## Faceplate Option Ordering

faceplate series	faceplate options finish
Choose faceplate series number	Choose finish number

## Example of Faceplate Option Ordering

(b) To include a faceplate option, order as a second line item, write:

- KM-630

To order a second faceplate option in a 630 finish, write:

- J2-630

## Accessories Model Ordering

accessories model
Choose accessories

## Example of Accessories Model Ordering

(c) To add accessories to your electric strike, write the following on a separate line:

- 2006M Plug-in Buzzer

